



LensCoat® Nikon Z 600 f6.3 VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod foot from the rotating lens collar. This will allow for easy installation of pieces 2-7.

Piece 2

After removing the tripod mount foot slide piece 2 down the lens to front of the lens, tapered side towards the camera.

Piece 3 – control ring

Slide piece 3 down the lens to the control ring

Piece 4

Slide piece 4 down between the the control ring and the focus ring

Piece 5 – focus ring

Slide piece 5 on to the focus ring

Piece 6

Slide on piece 6 down to between focus ring and the lens collar

Piece 7 – lens collar

Carefully slide piece 7 over the lens collar, fitting the foot through the opening and the knob through the hole.

Piece 8

Slide on piece 8 by **carefully lining up the windows for the VR / Focus limiter**

****you should be able to slide the controls through the plastic window with your finger, some people like to punch small holes in the plastic to allow for easier access, if you choose to do this be careful as it is easy to destroy the window.**