



## **LensCoat® OLYMPUS M.ZUIKO DIGITAL ED 150-600MM** **INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place. The hole in this section lines up with the hood securing knob.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2-6. If you don't want to remove the foot, it is possible (more difficult) to loop the pieces around the foot and over the back of the lens.

### ***Piece 2***

Stretch and slide piece 2 down to just behind the front element.

### ***Piece 3***

Slide piece 3 down the lens to the zoom ring.

### ***Piece 4***

Slide piece 4 on aligning the window over switches. **For final placement, pull window slightly away from the lens and adjust to the left or right.**

### ***Piece 5***

Slide piece 5 down the lens to the focus ring.

### ***Piece 6***

Slide piece 6 on to the lens collar, aligning the cut outs for the tensions knob and the strap attachment lugs.

### ***Piece 7***

Slide on piece 7 over the last segment of the lens.

### ***Zoom Sock***

The LensCoat kit for the Olympus 150-600 includes an optional sleeve to cover the barrel that would be exposed when zooming. With the lens shade off stretch the elastic over the front of the lens onto piece 2 and then the other side onto section 3. Put the lens hood on and pull the elastic up onto the hood, position both sides where comfortable. As you zoom in the sleeve will stretch and when it's zoomed out it will slightly bunch up.

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728