## Montageanleitung CaNiS Objektiv-Ersatzfüsse





- 3 Entsprechend beim CaNiS-\* Sockel die richtigen mitgelieferten M4 Schrauben auswählen, dass diese genau soweit wie die Originalschrauben aus dem Original-Fuss herausragen. Dies gewährleistet die gleiche Einschraubtiefe.
- 4 CaNiS-\* Sockel mit den in Schritt 3 ausgewählten M4 Schrauben am Objektiv mit der Nase nach vorn montieren, die Objektivplatte OP-\*\*\* mit den 1/4" Schrauben und dem 5/32" Inbus-Schlüssel einschrauben, wobei abwechselnd jede Schraube um je eine Umdrehung festgezogen wird.
- 5 Die Position der OP-\*\*\* am CaNiS-\* Sockel kann individuell nach Bedarf (Schwerpunkt etc.) gewählt werden.
- 6 M3 Sicherheits-Stop-Schrauben an der Unterseite der OP-\*\*\* mit dem 2,5mm Inbus-Schlüssel montieren.

## Assembly instructions

CaNiS lens replacement feet





- For the CaNiS-\* base, select the appropriate M4 screws supplied so that they protrude from the original base exactly as far as the original srews! This ensures the same srew-in depth.
- Mount the CaNiS-\* base with the M4 srews selected in step 3 on the lens with the nose facing forward, screw in the lens plate OP-\*\*\* with the 1/4" screws and the 5/32" Allen key tightening each screw alternately by one turn.
- The position of the OP-\*\*\* on the CaNiS-\* base can be selected individually as required (center of gravity etc.).
- Mount the M3 safety stop screws on the bottom of the OP-\*\*\* using the 2,5mm Allen key.