



LensCoat® Nikon Z 400 f2.8 TC VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod foot from the rotating lens collar. This will allow for easy installation of pieces 2-7.

Piece 2

After removing the tripod mount foot slide piece 2 down the lens to front of the lens, tapered side towards the camera.

Piece 3 – Fn ring

Slide piece 3 down the ring with the Fn Ring

Piece 4

Slide piece 4 down between the Fn ring and the control ring

Piece 5 – control ring

Slide piece 5 on to the control ring

Piece 6

Slide on piece 6 down to between the control ring and focus ring

Piece 7 – focus ring

Carefully slide piece 7 to the focus ring in front of the lens collar

Piece 8

Slide on piece 8 lining up the cut outs for the lens strap attachment points and the tension knob being careful not to pull/stretch the hole too much to prevent tears.

Piece 9

Slide on piece 9 by **carefully lining up the windows for the VR / Focus limiter and the teleconverter. For final placement pull the window slightly away from the lens and adjust to the left or right.**
****you should be able to slide the controls through the plastic window with your finger, some people like to punch small holes in the plastic to allow for easier access, if you choose to do this be careful as it is easy to destroy the window.**

Piece 10

Slide piece 10 onto the rear section of the lens, lining up the small hole with the white dot for alignment.