



## **LensCoat® Canon 600 f4 IS III INSTRUCTIONS**

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Piece 1 has a hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2-6.

### ***Piece 2***

After removing the tripod mount foot slide piece 2 down below the focus recall ring, tapered side towards the camera.

### ***Piece 3***

Slide piece 3 down to the focus recall ring.

### ***Piece 4***

Slide piece 4 down to the focus ring.

### ***Piece 5- IS and Distance Scale window***

Slide piece 5 on by **carefully lining up the IS and distance scale windows and slide into place being careful not to get the plastic windows caught on the rotating collar knob or strap attachment. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.**

**\*\*you should be able to slide the controls through the plastic window with your finger, some people like to punch small holes in the plastic to allow for easier access, if you choose to do this be careful as it is easy to destroy the window.**

### ***Piece 6***

Slide on piece 6 by lining up the hole to the rotating collar adjustment and the cutout for the lens foot and slits for the straps being careful not to pull/stretch the hole too much to prevent tears.

### ***Piece 7***

Carefully slide piece 7 down the lens aligning the AF/MF switches. **For final placement, pull the distance scale window slightly away from the lens and adjust to the left or right.**

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728