



LensCoat® Canon RF 24-105mm f/2.8L IS INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Remove the lens foot to allow easy fitting of sections 2-9.

Piece 2

Slide piece 2 down the lens to the front of the lens.

Piece 3

Slide piece 3 down the lens to the control ring.

Piece 4

Slide piece 4 down the lens to the focus ring.

Piece 5

Slide piece 45 down the lens to the section with the control buttons.

Piece 6

Slide piece 6 down the lens to the zoom ring.

Piece 7

Slide piece 7 down the section in front of the iris ring, aligning the window with the iris ring lock.

Piece 8

Slide piece 8 down the lens to the iris ring.

Piece 9

Slide piece 9 on to the lens collar aligning the lens foot with the gap.

Piece 10- AF / IS and lock windows

Slide piece 10 on to the rear of the lens by **lining up the AF / IS and lock windows**. For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728