



LensCoat® Canon 24-105 f/4L IS II INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place lining up the scalloped sections.

Piece 2

With the lens hood removed, stretch and slide piece 2 down to the focus ring.

Piece 3

Slide piece 3 over the lens and position it in between the zoom ring and the focus ring. Lining up the window for AF control, distance scale and hole for the lock switch. **For final placement pull the window slightly away from the lens and adjust to the left or right.**

****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this be careful as it is easy to destroy the window**

Piece 4

Slide on piece 4 onto the zoom ring by lining up the notch to the lens mount mark (red dot) on the lens being careful not to pull/stretch the hole too much to prevent tears.

Zoomed Lens Barrel

The LensCoat® Canon 24-105 f/4L IS II lens cover kit includes an optional piece that can be affixed to the lens via the Velcro strip **ONLY** when the lens is fully extended

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728