



LensCoat® OLYMPUS M.ZUIKO DIGITAL ED 150-400MM F4.5 **TC1.25X IS PRO INSTRUCTIONS**

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Remove the tripod mount foot from the rotating lens collar by unscrewing the 4 hex screws. This will allow for easy installation of pieces 2-6. If you don't want to remove the foot, it is possible (more difficult) to loop the pieces around the foot and over the back of the lens.

Piece 2

Stretch and slide piece 2 down the lens to just after the focus ring.

Piece 3

Slide piece 3 down the lens to the focus ring.

Piece 4

Slide piece 4 down the lens between the zoom and focus ring.

Piece 5

Slide piece 5 down the lens between the zoom ring.

Piece 6

Slide piece 6 on aligning the window over AF/MF/IS and focus limiter switches. **For final placement, pull window slightly away from the lens and adjust to the left or right.**

Piece 7

Slide on piece 7 over the last segment of the lens aligning the open window with the teleconverter switch. You can slide the bottom of the window below the slide or keep it above.

Rotating Lens Collar

The LensCoat® cover kit includes an optional strip of neoprene with adhesive tape applied to the back. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728