



LensCoat® Canon 200 f/2 IS INSTRUCTIONS

Piece 1 - Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a ¼ inch hole at one end of the cover to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover in to place without putting too much stress on the lock knob hole.

Piece 2

With the lens hood removed, stretch and slide piece 2 down from the glass to just above the rotating lens collar. This piece can also be put on by sliding down the lens and around the lens foot.

Piece 3

Carefully slide it down the lens aligning the distance scale, IS controls and limiting switches. **For final placement, pull the distance scale window slightly away from the lens and adjust to the left or right.**
****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this, be careful as it is easy to destroy the window**

Piece 4

Carefully slide it down the lens aligning the AF/MF switches. **For final placement, pull the distance scale window slightly away from the lens and adjust to the left or right.**
****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this, be careful as it is easy to destroy the window**

Rotating Lens Collar

The LensCoat® for the 200 f/2 IS lens cover kit includes a strip of neoprene with adhesive tape applied to the back. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done then remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728