



LensCoat® Nikon 500VR INSTRUCTIONS

Piece 1- Lens Hood Cover

Remove the lens hood cover from the lens. Piece 1 has a ¼ inch hole at one end of the cover seam to accommodate for the lens hood locking knob. Carefully slide and stretch the lens cover into place without putting too much stress on the lock knob hole.

Remove the tripod mount foot from the rotating lens collar. This will allow for easy installation of pieces 2, 3, and 4 or carefully loop the pieces around the foot over the lens.

Piece 2

After removing the tripod mount foot, slide piece 2 down below the focus ring, tapered side towards the camera.

Piece 3

Slide piece 3 over the lens aligning the distance, AF mode and limiting switches. **For final placement pull the distance scale window slightly away from the lens and adjust to the left or right.**

****You should be able to slide the controls through the plastic window with your finger. Some people like to punch small holes in the plastic to allow for easier access. If you choose to do this, be careful as it is easy to destroy the window.**

Piece 4

Slide piece 4 down just below the rotating lens collar.

Piece 5

Carefully slide piece 5 down the lens. There is a small hole for the filter knob and a slit for the strap. **Be extra careful when putting this piece on. Do not put too much stress on the holes and slit.**

Rotating Lens Collar

The LensCoat® Nikon 500VR lens cover kit includes one strip of neoprene with adhesive tape applied to the back. Cut out the desired length for the parts of the lens collar you want to cover. Cut the longest piece first. After all the cutting is done, remove the adhesive tape backing by carefully folding back a small corner and apply to the lens collar.

LensCoat.com®
80 Throckmorton Street
Freehold, NJ 07728