



## LensCoat® Sony 400-800 INSTRUCTIONS

### ***Piece 1- Lens Hood Cover***

Remove the lens hood cover from the lens. Carefully slide and stretch the lens cover into place.

Remove foot from rotating collar for easy placement of pieces 2-7

### ***Piece 2***

With the rotating collar removed, stretch and slide piece 2 down to just above the zoom ring.

### ***Piece 3***

Slide piece 3 down to the zoom ring.

### ***Piece 4***

Carefully slide piece 4 down the lens just after the focus ring.

### ***Piece 5***

Carefully slide piece 5 down to the focus ring.

### ***Piece 6***

Slide piece 6 down to just after the rotating collar.

### ***Piece 7***

Carefully slide on piece 7 by lining up the hole to the rotating collar adjustment and the cutout for the lens foot on the lens being careful not to pull/stretch the hole too much to prevent tears.

### ***Piece 8***

Slide piece 8 down on the last section of the lens aligning the window for the AF/OSS switches. **For final placement pull the windows slightly away from the lens and adjust to the left or right.**

LensCoat.com®  
80 Throckmorton Street  
Freehold, NJ 07728