
About the P-30

The P-30 is a 4.43" long, double dovetail, Arca-Swiss style quick-release plate. It is used to connect a camera lens, fitted with both a rotation collar and tripod mounting foot, to a compatible quick-release clamp. Wimberley plates are compatible with most Arca-Swiss style quick-release clamps, such as those made by Wimberley, Really Right Stuff, Kirk Enterprises, Markins, Arca-Swiss, Foba, Graf and others.

- Installation Instructions -

- **1. Determine the number of screws you need.** If your lens foot has **more than one mounting hole**, it is recommended that more than one hole be used to mount the plate to keep the plate from twisting on the foot. For a lens foot with **one mounting hole**, see (*Fig. 4*) below.
- 2. Use the threaded end of the slot to remove or add screws




- **3. Install safety stop screws** (*Fig.* 6 on p. 2). This is not required, but it is highly recommended to insure the safety of your gear.
- **4. Determine the size of the mounting hole(s).** If your lens foot has **one or more 3/8" mounting holes,** install the reducer bushing into the 3/8" mounting hole. Wimberley sells additional bushings.
- **5. Attach the lens plate to the foot of your lens.** When removing or installing the plate, loosen screws gradually while gently pulling the plate flush against the screw caps to prevent binding of the screw threads in the center slot of the plate.







If your lens has only one fastener, you can keep the plate from twisting on the lens foot by positioning the two raised nubs on the back of the plate flush against the back of the lens foot (*Fig. 2*). If you prefer to have the plate extend behind the lens foot, you can seat the two nubs against the front of the foot (*Fig. 3*).



— Using Flash Brackets -

Wimberley lens plates have a double dovetail cross-section. The upper dovetail allows you to attach Wimberley Flash Brackets as well as other 3rd party quick-release style brackets.





Wimberley plates are also made to accommodate older Really Right Stuff (RRS) and Kirk screw-mount flash brackets


NOTE: When using older Kirk screw-mount flash brackets, you must install the two extra safety stop screws in the counter-bored holes in order to keep the bracket from twisting on the plate.



Figure 6


- Using the Optional Safety-Stop Screws -


Your Wimberley foot comes with four safety stop screws and a matching hex key. Two of these screws are intended to be screwed into the small bottom threaded holes in the front and back of the plate (*Fig. 6*) to serve as stops that prevent the plate from accidentally sliding out of the quick-release clamp. If you opt to use both stops, you must open the jaws of the quick-release clamp wide enough to load your lens from the top (instead of sliding it in).





(Required with Safety Stop screws)


Top Loading is less convenient, but you can be certain that your lens will not slide out of the clamp.











Thank you for your interest in Wimberley products. If you have any questions or comments please feel free to contact us.